Coupe:

<Windshield/Door Opening>

unit: mm (in)

Ⓐ
Dashboard upper cowl cover mounting hole



Ⓑ
Windshield opening flange notch (2 places)



Ⓒ
Roof convex bead



Ⓓ、Ⓔ、Ⓕ、Ⓖ
Door opening flange notch (4 places)





<Rear Window/Trunk Lid Opening>

Ⓗ、Ⓘ
Rear window opening flange notch (3 places)



Ⓙ
Parcel shelf depression bead



Ⓚ
Trunk gutter area convex bead



Ⓛ
Outer panel flange end (2 places)



Ⓜ
Trunk seal flange water drain hole